EKET



Design and Quality
IKEA of Sweden

English

WARNING

Children have died from furniture tipover.To reduce the risk of furniture tipover:

ALWAYS install anti-tip device provided.

NEVER put a TV on this product.

NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves.

NEVER open more than one drawer at a time.

Place heaviest items in the lowest drawers.


Ø 8 mm
(5/16")






?
IKEA




10093081

12x

10093082

12x

108444

6x

101313

2x


152650

2x


152651

2x


141413

2x


141414

2x


131372

4x


133127
155201

2x


139477
155200

2x


10119658
10119673

4x


10119600

4x


139467
155197

2x


139468
155198

2x


152470
155675

1x



1x

1





2



3



4



5





6





7



8



9







10

11



12









13





14






EKET


EKET


AA-1908823
AA-1908823
AA-1908823



15



16



17



18



19


2x
10119600
10119658
10119673
2x
10119600
10119658
10119673

20



21



22



23



24




4x


Click!

© Inter IKEA Systems B.V. 2024
2025-03-24 AA-2578574-4